



Installation Guidelines


- 1 Pull the battery tab to activate the sensor.




- 2 Make sure the mounting surface is clean and dry.



- 3 Remove the adhesive backing from the sensor.



- 4 Mount the sensor at the desired location and apply light pressure for 2 seconds to ensure proper adhesion.



- ⊗ Sensor should be placed **at least 1 m (3ft)** from doors, windows, air supply, air vents or any other heating or cooling source that can affect the temperature or humidity measurement.

